

SAT-Kabel®

Self Repair

TVmeter HD-T / TVmeter HD

How to FORMAT HARD DISK of my instrument ?

Tvmeters using the latest technology where the hardware is looking more and more like a computer. For this reason, in the event of loss TV or SAT memory planes should be performed "**FORMAT HARD DISK**" to cleanse the memories, before reloading the memory Pan.

Below we listed the procedures for "**FORMAT HARD DISK**"




Figure 1: Menu selection "FORMAT HARD DISK"



Figure 2: Start-Up menu

FORMAT HARD DISK

To be performed always in the event of loss of memory plans for TV and SAT before reloading the TV & SAT memory Plan

CAUTION: The following procedure will erase all memories of the Instrument. At the end you will have to reload the TV & SAT memory plans and SW tool for rehabilitating LANGUAGE MENU.

1. Turn on the meter, press the power button **HOME** (red button) to display the on-screen display (HOME MENU);
2. **Press and HOLD for 10 seconds AT THE SAME TIME the 3 mechanical buttons, SPECT, PLAN and VOLUME;**
3. Wait until the screen of the instrument show a new menu (Figure 1)
4. Select "**FORMAT HARD DISK**" and confirm
CAUTION: NOT SELECT and NEVER use the OTHER ITEMS
5. Wait for the end of process;
6. When the process is finish, shut down the instrument;
7. Turn the instrument on and immediately after turning it on, **press and hold the VOLUME button until the completion of the start-up phase.**
On the screen, at the bottom right, you will see a red square (Figure 2)
8. Next, load the memory plans and TV & SAT (from your PC or from us) through the interface program **PC SW TVmeter...** previously installed in your PC
ALWAYS MAKE SURE YOU HAVE INSTALLED the LATEST VERSION RELEASED cancel the old one.
9. When finished, turn off and subsequently turn on the instrument;
10. Load the latest version of SW (otherwise the meter restart only with the English language)
11. Turn on the instrument and verify proper operation.